




# **AC200MAX**

## **Wiring Manual**

**Poweroak B.V**

## Connect the powerstation to a solarpanel



1. Connect the two cables in the same colored cables.
2. Connect the yellow connector into the other yellow connector.
3. Connect the round connector to the powerstation.
4. Make sure in the settings the powerstation is in PV charging mode.

## Connect the powerstation in series



If you want to connect the power station in series, connect the black cable of one panel to the red cable of the other panel. with the red and black cable that are not yet connected you can continue with the explanation on page 2.